



ROZTEČ VRTÁNÍ C (mm)	PRŮMĚR (mm)	VÝŠKA H (mm)	SATIN NIKL	SATIN CHROM	CHROM	MOSAZ
KNOPKA	18	23	35261	35262	35263	-
KNOPKA	25	32	35271	35272	35273	35274



ROZTEČ VRTÁNÍ C (mm)	PRŮMĚR (mm)	VÝŠKA H (mm)	SATIN NIKL	SATIN CHROM	CHROM	BROUŠENÝ NIKL
KNOPKA	15	24	157305	157306	157308	157307



ROZTEČ VRTÁNÍ C (mm)	PRŮMĚR (mm)	VÝŠKA H (mm)	SATIN NIKL	SATIN CHROM	CHROM	BROUŠENÝ NIKL	ČERNÁ
KNOPKA	15,5	27	157289	157290	157292	157291	157293
KNOPKA	20,5	34,5	157294	157295	157297	157296	157299

